Matelec FMS-12080 MOTION SENSOR INSTRUCTIONS





SUMMARY

The FMS-12080 Motion sensor is a dual (surface or flush) mount sensor, and utilises passive infrared technology to detect and identify motion, night and day.

Upon detection, the connected lighting load will illuminate for a user determined period of time. An integral daylight sensor ensures day or night only operation.

SPECIFICATIONS

Power Source:	220V - 240VAC
Power Frequency:	50HZ
Time delay:	Min 5 seconds Max 40 minutes
Rated Load:	2000W (Incandescent) 600W (Fluro) 200W (LED)
Detection distance:	22m (for normal detection)
Detection range:	360°
Cut out hole:	85mm (flush mount)
Manual Override:	No
Weatherproof Rating:	IP44 (Surface Mounted) IP20 (Flush mount
Warranty:	5years
Dimensions:	105mm x 105mm x 37mm 3
No of wires:	wire

INSTALLATION

Exceeding the maximum rated load may cause overheating and probable failure of this sensor. Please exercise care!

Note: All electrical connections relating to this installation must be carried out by a suitably qualified and registered electrician.

SURFACE MOUNT TO CEILING (Fig 1)

- 1. Remove the front cover
- 2. Unscrew the cable clamp, and remove the Junction Box and Terminal Block
- 3. Use the Base as a template to mark the screw holes into the ceiling. Pre-drill the lining to depth of 35mm and fit the plastic plugs, and then affix the Base securely. Care should be taken to avoid drilling or screwing any concealed services inside the ceiling void.
- 4. Connect circuit wiring to the terminal block as labeled.
- 5. Secure the Junction box & Terminal block to the PIR and tighten cable clamp over Mains Cable.
- 6. Carefully align the male terminal pins, click the PIR body onto the Base then re-fit the front cover.



RECESS MOUNT TO CEILING (Fig 2)

- 1. Unscrew the Cable Clamp, remove the Junction Box and Terminal Block.
- 2. Discard the Base piece for recess mount applications not required
- 3. Connect circuit wiring to the terminal block as labelled
- 4. Refit the Terminal Block, Junction Box and Cable Clamp.
- 5. Fit springs, carefully lift the spring clips into the 82-88mm diameter hole, and recess the PIR to the ceiling. The spring clips will secure the unit. Refit the front cover.



SET UP AND ADJUSTMENT

LIGHT CONTROL SETTING:

The Lux control is a built-in sensing device (photocell) that detects daylight and darkness.(*) position denotes the light can activate during daylight and night. (\mathbb{C}) position denotes the light can activate only at night. You can set the unit to operate at the desired switch on level by adjusting the LUX knob.

TIME SETTING:

The duration time is the length of time the circuit stays `on' after activation. The duration time can be adjusted from 5 seconds to 40 minutes. Rotating the TIME knob from (+) to (-) will reduce the duration time. Note: Once the circuit has been triggered by the PIR sensor any subsequent detection will start the timed period again from the beginning.

SENSITIVITY SETTING (REACH):

The sensitivity set to (+) provides the maximum distance which PIR Sensor can be triggered by body movement. Turning the SENS knob from (+) to (-) will decrease both the sensitivity and activation zone.

SETTING THE CONTROLS

- 1. Put the LUX control knob to light (*) position, turn the wall switch on and wait half a minute for the control circuit to stabilize. At this stage ensure that the TIME control knob is set at minimum duration time (-) position. The connected circuit will now switch on and remain on for about 30 seconds (within 60 seconds).
- 2. Have another person move across the desired perimeter of the area to be scanned and slowly adjust the SENS knob until the unit activates. Note reducing SENS will reduce both normal and occupancy zones
- 3. To set the light level at which the lights will automatically switch "on" at night, turn the LUX con trol knob from daylight (*) to night (C). If the lights are required to switch on earlier, e.g. Dusk, wait for the desired light level, and then slowly turn the LUX control knob towards daylight while someone walks across the center of the area to be detected. When the lights activate, release the LUX control knob. You may need further slight adjustments to achieve your ideal light level setting
- 4. Once LUX and SENS are calibrated, adjust TIME to suit site requirements.
- 5. Duplicate these settings for similar locations

